


Model No.

CHX-30 Series



INSTALLATION INSTRUCTIONS AND OPERATION MANUAL

IMPORTANT READ THIS FIRST

READ BEFORE INSTALLATION

- 1. Carefully check all contents of packages;
- 2. Thoroughly inspect the unit for any cosmetic damages or defects;
- 3. Test the unit before installation;
- 4. Have a certified contractor/electrician do the installation.

IF THERE IS ANY PROBLEM:

- 1. <u>DO NOT INSTALL THE UNIT AND KEEP ALL ORIGINAL</u> PACKAGING MATERIAL.
- 2. Have your original proof of purchase and product serial number ready.

Call 1-877-BUY-KOBE (289-5623); or e-mail to info@koberangehoods.com to report the problem

NO RETURN, NO REFUND, NO EXCHANGE IF:

- 1. PRODUCT HAS BEEN INSTALLED
- 2. KNOCK-OUT HOLES HAVE BEEN PUNCTURED
- 3. MISSING ORIGINAL PACKAGING MATERIAL AND/ OR PARTS

[ENGLISH]

- READ AND SAVE THESE INSTRUCTIONS -

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	
COMPONENTS OF PACKAGE	3
INSTALLATION	4
OPERATION INSTRUCTIONS	
MAINTENANCE	10
SPECIFICATIONS	11
MEASUREMENTS & DIAGRAMS	12
PARTS LIST	14
CIRCUIT DIAGRAM	17
TROUBLE SHOOTING	14
DISCLAIMER	19
WARRANTY	20
PRODUCT REGISTRATION	22

- READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING -

ALL WIRING MUST BE DONE BY A PROFESSIONAL AND IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRICAL CODES

IMPORTANT SAFETY INSTRUCTIONS

- PLEASE READ THIS SECTION CAREFULLY BEFORE INSTALLATION -

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR PERSONAL INJURY, OBSERVE THE FOLLOWING:

- 1) Installation and electrical wiring must be done by qualified professionals and in accordance with all applicable codes and standards, including fire-rated construction.
- 2) When cutting or drilling into wall or ceiling, be careful not to damage electrical wiring or other hidden utilities.
- 3) Ducted fans must be vented to the outside.
 - a) Before servicing or cleaning unit, open the light panel and SWITCH POWER OFF AT SERVICE PANEL.
 - b) Clean all grease laden surfaces frequently. To reduce the risk of fire and to disperse air properly, make sure to vent air outside. DO NOT vent exhaust air into wall spaces, attics, crawl spaces or garages.

NOTE

- This warranty is invalid without an authorized agent's receipt or if unit is damaged due to misuse, poor installation, improper use, mistreatment, negligence or any other circumstances beyond the control of KOBE RANGE HOODS authorized agents.
- KOBE RANGE HOODS will not be held responsible for any damages to personal property or real estate or any bodily injuries whether caused directly or indirectly by the range hood.

AWARNING: TO REDUCE THE RISK OF PERSONAL INJURY IN THE EVENT OF A RANGE TOP GREASE FIRE:

- 1. Keep all fan, baffle/spacer/filter/oil tunnel/oil container and grease-laden surfaces clean. Grease should not be allowed to accumulate on fan, baffle/spacer/filter/oil tunnel/oil container.
- 2. Always turn hood ON when cooking.
- 3. Use high settings on cooking range ONLY when necessary.
- 4. Do not leave cooking range unattended when cooking.
- 5. Always use cookware and utensils appropriate for the type and amount of food prepared.
- 6. Use this unit only in the manner intended by the manufacturer.
- 7. Before servicing, switch power off at service panel and lock service panel (if possible) to prevent power from switching on accidentally.
- 8. Clean ventilating fan frequently.

What to Do In The Event Of a Range Top Grease Fire

- SMOTHER FLAMES with a tight fitting lid, cookie sheet, or metal tray, and then turn off the burner.
 KEEP FLAMMABLE OR COMBUSTIBLE MATERIAL AWAY FROM FLAMES. If the flames do not go out immediately, EVACUATE THE AREA AND CALL THE FIRE DEPARTMENT or 911.
- NEVER PICK UP A BURNING PAN You May Get Burned.
- DO NOT USE WATER, including wet dishcloths or towels a violent steam blast will result.
- Use an extinguisher ONLY if:
 - a) You have a Class A, B, C extinguisher and know how to operate it.
 - b) The fire is small and contained in the area where it started.
 - c) The fire department has been called.
 - d) You can fight the fire with your back to an exit.

What to Do If You Smell Gas

- Extinguish any open flame.
- Do not try to turn on the lights or any type of appliance.
- Open all doors and windows to disperse the gas. If you still smell gas, call the Gas Company and Fire Department right away.

ACAUTION

- 1) For general ventilation use only. Do not use to exhaust hazardous or explosive materials and vapors.
- 2) To reduce the risk of fire, use only metal ductwork. Sufficient air is needed for proper combustion and exhausting of gases through the flue (chimney) to prevent back drafting.
- 3) Follow the heating equipment manufacturer's guideline and safety standards such as those published by the National Fire Protection Association (NFPA), and the American Society for Heating, Refrigeration and Air Conditioning Engineers (ASHRAE), and code authorities.
- 4) Activating any switch on may cause ignition or an explosion.
- 5) Due to the size and weight of this hood, two people installation is recommended.


A WARNING



ELECTRICAL SHOCK HAZARD – Can result in serious injury or death. Disconnect appliance from electric power before servicing. If equipped, the fluorescent light bulb contains small amounts of mercury, which must be recycled or disposed of according to Local, State, and Federal Codes.

COMPONENTS OF PACKAGE

(Must keep all material for returns or refunds)



♦ FOR MORE INFORMATION, PLEASE VISIT OUR WEBSITE www.KOBERangeHoods.com OR CONTACT KOBE RANGE HOODS AT (626) 775-8880.


INSTALLATION

PLEASE READ ENTIRE INSTRUCTIONS BEFORE PROCEEDING

Calculation before Installation

To calculate installation, please refer to TABLE 1. (All calculation in inches.)

- FOR UNDER THE CABINET -



ASAFETY WARNING

HOOD MAY HAVE VERY SHARP EDGES; PLEASE WEAR PROTECTIVE GLOVES IF REMOVING ANY PARTS FOR INSTALLING, CLEANING OR SERVICING.

NOTE: BE CAREFUL WHEN USING ELECTRICAL SCREWDRIVER, DAMAGE TO THE HOOD MAY OCCUR.

Preparation before Installation

NOTE: TO AVOID DAMAGE TO YOUR HOOD,
PREVENT DEBRIS FROM
ENTERING THE VENT OPENING.

- Decide the location of the venting pipe from the hood to the outside. Refer to Figure 1.
- A straight, short venting run will allow the hood to perform more efficiently.
- Try to avoid as many transitions, elbows, and long run as possible. This may reduce the performance of the hood.
- Temporarily wire the hood to test for proper operation before installing.
- Important: Peel protective film off the hood (if any).
- For installing under the cabinet with recessed bottom, attach 4-inch wide wood filler strips (not included) on each side. Refer to Figure 2.
- Using reference on Page 13 and 14 to measure and create access opening for electrical wires and exhaust under the cabinet {refer to Vent Option Installation on 7}. Refer to Figure 3.
- Using reference on Page 13 and 14 to position the mounting screws (not included) underneath the cabinet. Refer to Figure 4.

Install Lights before mounting hood

To install the light fixture:

 Insert the light fixture into the socket and turn it clockwise to secure the light fixture.

Figure 1




Figure 2




Figure 3





Figure 4



Vent option installation

- 1. Choose the require vent option.
 - NOTE: If the hood is to be installed as ductless application, please do not remove any duct knockout located at the top or the back of the hood.
- 2. For 7" Round vent installation only:
 - Using a flat-head screwdriver to remove the 7" duct knockout. (Refer to Figure 5)
 - Attached the 7" exhaust plate using 8 screws (provided). Refer to Figure 6.
- 3. For 3-1/4" x 10" vent installation only:
 - Using a flat-head screwdriver to remove the top OR the rear 3-1/4" x 10" duct knockout. (Refer to Figure 7)
 - Attached the 3-1/4" x 10" exhaust plate using 6 screws (provided). Refer to Figure 8 for Top Vent OR Figure 9 for Rear Vent.
- 4. For ductless installation only.
 - Remove the recirculating plate located at the top of the hood, refer to Figure 10.
 - Reinstall the recirculating plate horizontally as shown in Figure 11.

Figure 5




Figure 6




Figure 7




Figure 8




Figure 9




Figure 10





Figure 11



Wiring to Power Supply

A

SAFETY WARNING

RISK OF ELECTRICAL SHOCK. THIS RANGE HOOD MUST BE **PROPERLY** GROUNDED. MAKE SURE THIS IS DONE **SPECIALIZED ELECTRICIAN** ACCORDANCE WITH ALL APPLICABLE NATIONAL AND LOCAL **ELECTRICAL** CODES. BEFORE CONNECTING WIRES, SWITCH POWER OFF AT SERVICE PANEL AND LOCK SERVICE PANEL TO PREVENT POWER FROM BEING SWITCHED ON ACCIDENTALLY.

- 5. Connect the electrical wires.
 - Connect three wires (black, white and green) to house wires and cap with wire connectors. Connect according to color: black to black, white to white, and green to green.

Hood Installation

CAUTION: If required to move the cooking range to install the hood, turn off the power on an electric range at the main electrical box. SHUT OFF THE GAS BEFORE MOVING A GAS RANGE.

6. Align screws with the mounting holes on top of the range hood, and push toward the wall to secure the unit in place. Refer to Figure 12 and Figure 13.

Figure 12





Figure 13



Final Assembly

- 7. To install the parametric panel:
 - Align the parametric panel at the back of the unit. Refer to Figure 14.
 - Push the unit upward, and slide the parametric panel forward into the notch to secure the panel. Refer to Figure 15.
 - Flip the parametric panel upward until it clicks into place. Refer to Figure 16.

CAUTION: MAKE SURE THE PARAMETRIC PANEL IS SECURE BEFORE RELEASING.

- 8. Turn power ON in control panel. Check all light and fan operation.
- 9. Make sure to leave this manual for the homeowner.

Figure 14




Figure 15






Figure 16



OPERATION INSTRUCTIONS

For models equipped with Rotary Switch:




To operate the fan function

- Turn the Speed Control clockwise to choose speed.
- Turn the Speed Control counterclockwise to "OFF".

To operate the light function

- Turn the Light Control clockwise to turn on the light.
- Turn the Light Control counterclockwise to "OFF".

For model equipped with Push Button:



To operate the fan function

- Press button to choose from speed.
 - 1 = Low Speed
 - o 2 = Medium Speed
 - o 3 = High Speed
- Press "0" to turn fan off.

To operate the light function

Press the Light Control to turn lights on and off.

MAINTENANCE

ASAFETY WARNING

NEVER PUT YOUR HAND INTO AREA HOUSING THE FAN WHILE THE FAN IS OPERATING.

Cleaning Hood Surface

ACAUTION: NEVER USE ABRASIVE CLEANERS, PADS, OR CLOTHS. DO NOT USE PAPER TOWEL ON STAINLESS STEEL.


For optimal operation, clean range hood and all baffle/spacer/filter/oil tunnel/oil container regularly.

*** Regular care will help preserve the appearance of the hood.

- 1. Use only mild soap or detergent solutions. Dry surfaces using soft cloth.
- 2. If hood looks splotchy (stainless steel hood), use a stainless steel cleaner to clean the surface of the hood. Avoid getting cleaning solution onto or into the control panel. Follow directions of the stainless steel cleaner. Caution: Do not leave on too long as this may cause damage to hood finish. Use soft towel to wipe off the cleaning solution, gently rub off any stubborn spots. Use dry soft towel to dry the hood.
- 3. DO NOT allow deposits to accumulate or remain on the hood.
- 4. DO NOT use ordinary steel wool or steel brushes. Small bits of steel may adhere to the surface and cause rusting.
- 5. DO NOT allow salt solutions, disinfectants, bleaches, or cleaning compounds to remain in contact with stainless steel for extended periods. Many of these compounds contain chemicals, which may be harmful. Rinse with water after exposure and wipe dry with a clean lint free cloth.

To Clean Filter

A CAUTION: CLEAN FILTER AND PARAMETRIC PANEL PERIODICALLY.



- 1. Remove parametric panel and aluminum filters.
- 2. Using a sponge, wash with warm soapy water. Dry completely before returning into place.

NOTE: MAKE SURE THE PARAMETRIC PANEL IS SECURE BEFORE RELEASING.

SPECIFICATIONS

Series CHX30 Series

CONSUMPTION / AMPERE 0.82 Ampere

VOLTAGE 120V 60Hz

NUMBER OF MOTORS 1

DESIGN 20-Gauge Seamless / Satin Finish

with

Glass Parametric panel or Stainless Steel Parametric panel

EXHAUST Top 7" Round with damper

Top 3-1/4" x 10" Rectangular with damper Rear 3-1/4" x 10" Rectangular with damper

CONTROLS - Rotary control system

- 5 Mechanical Push Buttons

LIGHTS 3-Watt LED x 2

HOOD DIMENSION 30" models – 29-3/4" x 21" x 6" (**W x D x H**) 36" models – 35-3/4" x 21" x 6"

		<u>Net</u>	<u>Gross</u>
WEIGHT (lbs)	30"	37	42
	36"	40	44

SPEEDLED SeriesAir Capacity (cfm)450Sone5.0

Specifications information is subject to change without notice.


MEASUREMENTS & DIAGRAMS

- ♦ All measurements in () are millimeters.
- ♦ All inch measurements are converted from millimeters. Inch measurements are estimated.


- FOR TOP VENTING -

BOTTOM VIEW BOTTOM VIEW 1/2" (13.7) 1-5/16" (34.2) 1-5/16" (34.2) Wall Wall 1-1/2" (39) 1-1/2" (39) 3-13/16" (97) 5-13/16" (148) 1" (Ф 25) 1" (Φ 25) 9-3/4" (248) 9-3/4" (248) 5-1/4" (133) 5-1/4" (133) 8" (Ф 203) 6-7/8" (176) 6-7/8" (176) 13-3/8" (340) 13-3/8" (340) 13-3/8" (340) 13-3/8" (340) 16-1/4" (414) 16-1/4" (414) 16-1/4" (414) 16-1/4" (414) Front of Hood Front of Hood

- FOR REAR VENTING -




- DIMENSIONS OF THE MODEL-



PARTS LIST


For models equipped with Push Button:

HOOD			
NO.	DESCRIPTION	MODEL /SIZE	PART NO.
1	Motor Mounting Plate		K-Y21-2355-P
2 Hood Frame	CH3030PD (30")	K-Y20-1248-Q	
	Hood Frame	CH3036PD (36")	K-Y20-1219-Q
3	Recirculating Box		K-Y36-0228
4	Light socket		K-GF F005-00000
5	Push Button Control		K-Y50-0087
6	Light Support		K-Y20-1273-P
7	Light / Control Panel	CH3030PD (30")	K-Y20-1278-Q
'	Light / Control Panel	CH3036PD (36")	K-Y20-1276-Q
8	Light fixture	For LED lighting system	Y53-0442
9	Motor		K-Y54-0005
9	IVIOLOI		K-Y54-0005-1
10	Turbine Impeller		K-Y23-0049
	Bottom Casing	CH3030PD (30")	K-Y21-2743-6
	Bottom Casing	CH3036PD (36")	K-Y21-2693-6
12	Parametric Panel support clip (Left)		K-Y23-0041
13	Safety Screen		K-Y36-0227
14	Magnetic Mechanism		K-Y23-0040
15	Parametric Panel support clip (Right)		K-Y23-0042
16	Aluminum Filter		K-Y23-0043
		Glass Parametric Panel (30")	PPG30
17	Parametric Panel	Glass Parametric Panel (36")	PPG36
17		Stainless Steel Parametric Panel (30")	PPS30
		Stainless Steel Parametric Panel (36")	PPS36
18	Recirculating Panel		K-Y21-2732-P




For models equipped with Rotary Switch:

HOOD			
NO.	DESCRIPTION	MODEL /SIZE	PART NO.
1	Motor Mounting Plate		K-Y21-2355-P
2 Hood Frame	Hood Frama	CH3030RD (30")	K-Y20-1248-Q
		CH3036RD (36")	K-Y20-1219-Q
3	Recirculating Box		K-Y36-0228
4	Light socket		K-GF F005-00000
5	Speed Control		K-Y50-0085
6	Light Control		K-Y50-0084
7	Light Support		K-Y20-1273-P
8	Light / Control Panel	CH3030RD (30")	K-Y20-1249-P
0	Light / Control Panel	CH3036RD (36")	K-Y20-1220-P
9	Light fixture	For LED lighting system	Y53-0442
10	Rotary Knobs		K-Y32-0445
11	Motor		K-Y54-0005
111	Wiotol		K-Y54-0005-1
12	Turbine Impeller		K-Y23-0049
13 Bottom Casing	Rottom Casing	CH3030RD (30")	K-Y21-2743-6
	Bottom Casing	CH3036RD (36")	K-Y21-2693-6
14	Parametric Panel support clip (Left)		K-Y23-0041
15	Safety Screen		K-Y36-0227
16	Magnetic Mechanism		K-Y23-0040
17	Parametric Panel support clip (Right)		K-Y23-0042
18	Aluminum Filter		K-Y23-0043
	Parametric Panel	Glass Parametric Panel (30")	PPG30
19		Glass Parametric Panel (36")	PPG36
19		Stainless Steel Parametric Panel (30")	PPS30
		Stainless Steel Parametric Panel (36")	PPS36
20	Recirculating Panel		K-Y21-2732-P




For models equipped with Slide Switch:

HOOD			
NO.	DESCRIPTION	MODEL /SIZE	PART NO.
1	Motor Mounting Plate		K-Y21-2355-P
	Hood Frame	CH3030SD (30")	K-Y20-1248-Q
		CH3036SD (36")	K-Y20-1219-Q
3	Recirculating Box		K-Y36-0228
4	Light socket		K-GF F005-00000
5	Light Support		K-Y20-1273-P
6	Light / Control Daniel	CH3030SD (30")	K-Y20-1296-Q
0	Light / Control Panel	CH3036SD (36")	K-Y20-1297-Q
7	Light fixture	For LED lighting system	Y53-0442
8	Slide Switch		K-Y50-0088
9	Motor		K-Y54-0005
9			K-Y54-0005-1
10	Turbine Impeller		K-Y23-0049
11	Bottom Casing	CH3030SD (30")	K-Y21-2743-6
- ' '		CH3036SD (36")	K-Y21-2693-6
12	Parametric Panel support clip (Left)		K-Y23-0041
13	Safety Screen		K-Y36-0227
14	Magnetic Mechanism		K-Y23-0040
15	Parametric Panel support clip (Right)		K-Y23-0042
16	Aluminum Filter		K-Y23-0043
		Glass Parametric Panel (30")	PPG30
17	Parametric Panel	Glass Parametric Panel (36")	PPG36
		Stainless Steel Parametric Panel (30")	PPS30
		Stainless Steel Parametric Panel (36")	PPS36
18	Recirculating Panel		K-Y21-2732-P




CIRCUIT DIAGRAM


For models equipped with Push Control:



For models equipped with Rotary Switch:



For models equipped with Slide Switch:



TROUBLE SHOOTING

Issue	Possible Cause	Solution
After Installation,	The power is not on.	Make sure the circuit breaker and the unit's power is
both motors and		ON. Use a voltage meter to check the power supply.
lights are not	The wire connection is not secure.	Check and tighten wire connection.
working.	The control panel is defective.	Replace the control panel.
Lights are	The motor is defective.	Replace the motor.
working, but	The capacitor is defective.	Replace capacitor.
motor is not.	The control panel is defective.	Replace the control panel or processing board.
The range hood is vibrating.	The blower system is not secure.	Tighten the turbine impeller/squirrel cage and air chamber.
	The turbine impeller/squirrel cage is not balanced.	Replace the turbine impeller/squirrel cage.
	Hood is not secured in place.	Check the installation of hood, tighten the mounting bracket.
The motor is working, but the lights are not	Light bulb(s) is defective.	Try placing the trouble light bulb(s) to a working socket, if the bulb(s) still doesn't work; replace the halogen light bulb(s).
working.	The light wiring(s) is loose.	Check wire continuity from control panel to light housing(s).
	The control panel is defective.	Replace the control panel.
The range hood is not venting	The range hood is installed outside of the manufacturer recommended clearance.	Adjust the clearance, the distance between the range hoods and cook top, from 27" to 30".
out correctly.	There is no make-up air inside the house.	Open the window to enhance the performance of the range hood by creating sufficient make-up air.
	Obstacle blocking the pipe work.	Remove all obstacles from the duct work.
	The pipe size is smaller than the suggested pipe size.	Change the ducting according to the manufacturer suggestion.
Cold air is coming into the home.	The pipe connection is not properly sealed.	Check the pipe installation.

DISCLAIMER

1. CAREFULLY INSPECT ALL ITEMS FOR DAMAGES BEFORE ACCEPTING DELIVERY. NOTE ANY DAMAGES ON THE FREIGHT BILL OR EXPRESS RECEIPT. REQUEST NAME AND SIGNATURE OF THE CARRIER'S AGENT AND KEEP COPY TO SUPPORT YOUR CLAIM.

Upon acceptance of items, owner assumes responsibility for its safe arrival. Report damages to the carrier and file a claim immediately. Failure to do so may result in the denial of your claim. The carrier will furnish you with necessary forms for filing a claim.

DAMAGES CAUSED DURING TRANSIT ARE NOT COVERED UNDER OUR WARRANTY.

2. PLEASE INSPECT CONTENTS OF PACKAGE(S) CAREFULLY UPON RECEIVING!

We must be notified in writing of any damages and/or missing parts within the allocated days upon your receipt of package(s). Contact your local KOBE dealer or distributor or call KOBE for the time limit.

CLAIMS WILL NOT BE ACCEPTED AFTER THE ALLOCATED DAYS.

NOTE: ITEMS WERE THOROUGHLY TESTED AND CAREFULLY PACKED IN OUR FACTORY BEFORE SHIPPING.

3. Products must be returned in good working condition with ALL original parts and documentation packed in ALL original cartons, fillers and shipping cartons. A restocking fee of 25% will be charged for all approved return(s).

EXCHANGES OR RETURNS MAY NOT BE ACCEPTED IF ANY PACKAGING IS MISSING.

4. MAKE SURE TO INSPECT THE HOOD FOR DAMAGES AND DEFECTS BEFORE INSTALLATION. Appearance flaws of the hood found after installation and not affecting hood performance is not covered under our warranty for returns or exchanges. Service visits not covered under warranty will carry a service charge.

A) Before Installation: Return for exchange or refund (please see above for acceptable returns).

B) After Installation: **NO** exchange or refund.

WARRANTY CERTIFICATE

KOBE Range Hoods (referred to herein as "we" or "us") warrants to the original purchaser (referred to herein as "you" or "your") all products manufactured or supplied by us to be free from defect in workmanship and materials as follows:

TWO-YEAR LIMITED WARRANTY FOR PARTS AND LABOR ON KOBE PREMIUM SERIES:

For two years from the date of your original invoice from a KOBE authorized dealer, we will, at our sole discretion, choose to repair or replace the product free of charge that failed due to manufacturing defects.

It is your sole responsibility to ensure the product is readily accessible for the service technician to perform repairs. The service technician will not, under any circumstance, remove, alter or modify any fixture built around and/or connected to the product to gain access to perform repairs.

During the two-year Limited Warranty period, additional charges may apply which include but are not limited to:

- Service technician travel charges if the requested service location is 30-miles out of KOBE's authorized service area
- Parts shipping expenses
- Un-installation of defective product and Installation of replacement product

EXTENDED BRILLIA WARRANTY (1-YEAR LABOR AND 2-YEAR PARTS) ON KOBE BRILLIA SERIES ONLY.

For two year from the date of your original invoice from a KOBE authorized dealer, we will provide free of charge parts and one year labor for Brillia Hoods that failed due to manufacturing defects. It is our sole discretion to choose to repair or replace defective parts.

Warranty Exclusions:

This warranty does not cover, including but not limited to the following:

- a. Improper installation.
- b. Any repair, alteration, modification not authorized by KOBE.
- c. Duct alteration, modification and connection.
- d. Incorrect electric current, voltage or wiring.
- e. Normal maintenance and service required for the product.
- f. Consumable parts such as light bulbs and carbon filters.
- g. Improper usage of the product that it is not intended for, such as commercial use, outdoor use and multi-family use.
- h. Normal wear and tear.
- i. Chips, scratches or dents by abuse or misuse of the product.
- j. Damages caused by accident, fire, flood and other Acts of God.
- k. Expenses incurred for service located outside of the designated service area.
- I. Purchases from unauthorized dealers.
- m. Removal fees of defective product and Installation fees associated with replacement product.

If we determine that the warranty exclusions listed above apply or if you fail to provide all necessary documentation for warranty service, you will be responsible for all expenses associated with the requested service, including parts, labor, shipping, travelling and any other expense related to the service request.

To qualify for warranty service, you must:

- 1. Have the **ORIGINAL** proof of purchase
- 2. Be the **ORIGINAL** purchaser of the product
- 3. Have the model number
- 4. Have the serial number
- 5. Have a description of the nature of any defect in the product or part

TO REQUEST WARRANTY SERVICE, PLEASE CONTACT THE KOBE RANGE HOODS SERVICE CENTER:

KOBE SERVICE CENTER
Tel: 1-855-800-KOBE (5623)

E-mail: kobe@adcoservice.com

PRODUCT REGISTRATION

Register Your Product!

Any covered failure occurring within one year of original purchase arising from defective workmanship or material in manufacture will at our discretion, replaced free of charge by KOBE Range Hoods as applicable. Keep proof of purchase (original invoice) handy for inspection.

If the range hood is sold by the original purchaser during the warranty period the new owner is protected until expiration of the original purchaser's warranty. See warranty section for complete warranty coverage information.

This appliance has been manufactured, tested, and inspected to the standards required by KOBE Range Hoods.

PLEASE MAIL IN YOUR WARRANTY REGISTRATION CARD AND PROOF OF PURCHASE TO:

KOBE Range Hoods 11775 Clark Street Arcadia, CA 91006 U.S.A.

RECORD THE FOLLOWING INFORMATION FOR YOUR RECORD:

Model No	 		
Serial No	 		
Purchased Date	 _/	_/	_
Purchased From:			

IMPORTANT: PLEASE KEEP A COPY OF YOUR SALE RECEIPT OR INVOICE HANDY WHEN REQUESTING FOR SERVICE.



http://www.KOBERangeHoods.com

This KOBE hood is made for use in the USA and CANADA only. We do not recommend using this hood overseas as the power supply may not be compatible and may violate the electrical code of that country. Using a KOBE hood overseas is at your own risk and will void your warranty.

Information subject to change without notice.

VER.120509