

ILLUSION DRYWALL ASSEMBLY

Installation must be performed exclusively by qualified installers and the drywall panel must be installed by a professional gypsum board installer. Here is a short list of instructions:

- Use fireproof gypsum board panels (compliant with art. 30 of IEC/EN 60335-2-31), suitable for the operating conditions in terms of temperature (at least 80° C) and humidity (at least 93%) reached during application;
- the total weight of the gypsum board should not exceed 4 kg;
- fix the gypsum board to the hood through the 6 fixing points C (diameter 4.5 mm) of which the metal panel is supplied;
- Use suitable mechanical components (not included in the assembly kit) to fix the plasterboard. We recommend the use of metric flat-head screws and nuts.

ASSEMBLY

- Cut the drywall according to metallic panel dimensions.
- Insert the drywall panel (thickness 10 mm) inside the metallic plate.
- Drill the panel in correspondence of the metallic panel holes.
- Screw the metric flat-head screws from external part (6 screws in the C positions indicated) and then fix them inside the metallic panel with the nuts.
- Grout holes and paint with the desired colors.

ATTENTION!!!

It's better to make all these operations with the hood not yet installed on the false ceiling.

